



MagIC 9000 – Analog Phone Line Set-up Short Range (RF) and Wired (Fixed)

- ✍ Before your MagIC 9000 terminal can process credit card or debit card transactions with Moneris (Financial Institution) or transfer data back and forth to your host PC you must have the modem base connected to an analog phone line/jack/outlet. This can be a shared line (use custom prefix or use suffix numbers to operate), but can only be an analog line (not digital). If you are unsure of the type of line/outlet/jack you have, it can be verified beforehand.

- ✍ Since 99.9% of all home phone sets are of the analog type it is preferable to utilize it for these testing purposes. Just plug in your home phone set into the phone line/outlet/jack you wish to use. If you get a dial tone its an analog line. If not, the line may be dead or digital. You may need to involve your local phone company technician to resolve this issue.

- ✍ Occasionally, companies block these lines with their local telephone companies not to accept outgoing direct-dialed long distance calls (10 digits). If this is the case, you will need to call your local phone system business contact to have additional direct-dialed outside line access to toll free numbers that begin with 1-800 and 1-877. Usually there is no fee for this change.

- ✍ For Communications to proceed a phone cord must be plugged between the analog phone line/outlet/jack and the MagIC 9000 base modem (plug into the connection closest to the centre of the base where it is marked PHONE LINE).